


## Adjustment of top patio door guide rollers

1. Remove operating panel from door.
2. Remove the guide rollers that are closest to the exterior of the door panel on the top.
3. Reposition the rollers closer to the exterior of the panel.
4. Silicone the hole that the screw from the roller was originally in.
5. Reinstall the patio door panel and check operation



*To adjust rollers remove the roller closest toward the exterior of the door panel and reposition closer toward the exterior edge of the panel.*

**Typical factory placement of rollers**