

Tightening the set screw in the top and bottom latch on the automatic multipoint gear

- Remove the handle from the door.
- Remove the multipoint gear from the door
- Please see below and follow steps 5 and 6 to tighten the latch

REVERSE AUTOMATIC LATCH Use 4mm Allen T-key

